



SHORT TYPE VALVE CORES

Instructions

1. Remove valve cap.
2. Use Victor Valve Tool (00714-8) to remove old core.
3. Turn core counterclockwise to remove. Tire will deflate rapidly.
4. Install new core, turning clockwise until tight.
5. Inflate to recommended pressure.
6. Reinstall valve cap.

WARNING: This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm. *Wash hands after handling.*

CENTROS DE VÁLVULAS CORTOS

Instrucciones

1. Quite la tapa de la válvula.
2. Use la herramienta Victor para válvulas (00714-8) a fin de retirar el centro antiguo.
3. Gírelo en sentido horario para extraerlo. El neumático se desinflará rápidamente.
4. Instale el nuevo centro, girándolo en sentido horario hasta que quede apretado.
5. Infle el neumático a la presión recomendada.
6. Vuelva a instalar la tapa de la válvula.

ADVERTENCIA: Este producto contiene sustancias químicas, incluyendo el plomo, que según el Estado de California causan cáncer, defectos congénitos u otro daño al sistema reproductor.

Lávese las manos después de usar el producto.

00710-8