SUPERDECK® Exterior Wood Cleaner

1440



General Description

SUPERDECK® WOOD CLEANER is a concentrated product formulated to remove foreign matter from wood including: oxidized (failed) coatings, dirt, grease, oil, pollen and surface stains caused by mildew. This formula dilutes with water depending on the amount of cleaning required. Follow label directions below to determine the cleaning strength needed.

Recommended Substrates

For all exterior wood.

Tinting & Base Color Information

Ready to use. Do not tint.

DB 1440

Features / Benefits

Removes Dirt & Grime
Removes Failed Oxidized Stains
Concentrated Formula
1 Gal of Cleaner Makes 4 Gal of Cleaning Solution

Product Application

APPLICATION:

Shake well before using. Wood Cleaner is supplied as a concentrate. Spray wood with water, then apply Cleaner with a brush, roller or pump up sprayer. Use synthetic brushes or rollers only. Wood Cleaner's thick formula may be used undiluted for difficult areas or vertical surfaces. For maximum effectiveness, keep Cleaner wet on surface by occasionally misting with water. Allow Cleaner to stay on surface approximately 15-30 minutes to soften and dissolve failed oxidized coatings. Wood Cleaner becomes extremely slippery once applied. Work on small enough areas to avoid walking on treated surface.

Product Application (cont.)

DILUTION INSTRUCTIONS:

GENERAL CLEANING: Mix 1 gallon of Wood Cleaner to 3 gallons of water for normal use.

MAINTENANCE CLEANING (FOR WOOD NOT BEING RE-COATED): Mix ½ gallon of Wood Cleaner to 3 ½ gallons of water, then follow instructions for application and rinsing.

RINSING:

Test a small area by scrubbing with a bristle brush to determine if the surface is ready for rinsing. When ready, scrub the surface with a firm bristle brush or long handled push broom. Rinse thoroughly with water using a garden hose or pressure washer. Do not exceed 1000 PSI when using a pressure washer. Rinse any residue from plants.

BRIGHTENING:

Wood species such as redwood, cedar and fir will tend to darken after being cleaned. Use Superdeck® Wood Brightener as the final step to brighten the wood and neutralize the surface before coating.

PRECAUTIONS:

Apply product at temperatures above 50° F. and below 90° F. Do not apply in direct sunlight if possible. Protect any aluminum surfaces (such as window frames) to prevent discoloration. Product will etch metal. If product makes contact with glass, rinse thoroughly before it dries. Mist any nearby vegetation with water before and after application.

COVERAGE:

100-200 sq. ft. per gallon and will vary depending on the dilution of Wood Cleaner to water.

CLEAN UP:

Clean all tools with water.



Product Application (cont.)

SAFE USE & STORAGE:

When using, do not eat, drink or smoke. W ash hands after use and before eating, drinking or smoking. Product is corrosive, avoid contact with metals such as aluminum. Do not transfer contents into a metal container or unlabeled container. Store in a well ventilated area. Keep container tightly closed when not in use. Protect from freezing. For exterior use only.

Physical Properties

DB1440 Exterior Wood Cleaner:

<u>CAS Number</u> <u>Ingredient</u> 7732-18-5 Water

13007-85-7 Sodium Glucoheptonate

1310-73-2 Sodium Hydroxide NON-PHOTOCHEMICALLY REACTIVE

VOC: 0 g/L

CAUTIONS:

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage.

FIRST AID: In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately.

WARNING: This product contains chemicals known to the State of California to cause cancer. DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.

Packaging

1-Gallon Container = 124 fl. oz. (3 7/8 U.S. Qt) 3.66 L

Product Guarantee

LIMITED WARRANTY: If this product, when applied according to label instructions to a properly prepared surface, fails to perform in accordance with applicable product literature, Duckback Products shall, upon presentation of proof of purchase to Duckback Products or its authorized representative, either replace an equivalent quantity of product free of charge or refund the original purchase price. This warranty shall not apply to any defect or damage resulting from improper surface preparation, structural defects, or failure of a previous product. This is your sole remedy under this warranty. To obtain performance under this warranty, contact Duckback Products at (800) 825-5382 or superdeck. com. You may be asked to contact the retailer from whom you purchased this product for further warranty instructions. THIS WARRANTY EXCLUDES (1) LABOR OR COSTS ASSOCIATED WITH LABOR FOR THE APPLICATION OR REMOVAL OF ANY PRODUCT, AND (2) ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

