



## **METAL SLOTTED HEAD VALVE CAPS**

### **Instructions**

1. Remove existing valve cap.
2. Check tire pressure and adjust to manufacturer's recommended pressure.
3. Replace with new valve cap.

Proper tire pressure improves gas mileage, handling, braking and durability.

**NOTE:** Not safe for use with TPMS valves or sensors. Cap may permanently bond to valve.

**WARNING:** This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm. *Wash hands after handling.*

## **TAPAS METÁLICAS PARA VÁLVULAS**

### **Instrucciones**

1. Quite la tapa de la válvula existente.
2. Revise la presión del neumático y ajústela según las recomendaciones del fabricante.
3. Reemplácela por la nueva tapa de la válvula.

La correcta presión del neumático ahorra gasolina y mejora la maniobrabilidad, la acción de los frenos y la durabilidad.

**NOTA:** No es seguro de usar con válvulas o sensores TPMS (sistema de supervisión de presión en neumáticos). La tapa puede quedar adherida permanentemente a la válvula.

**ADVERTENCIA:** Este producto contiene sustancias químicas, incluyendo el plomo, que según el Estado de California causan cáncer, defectos congénitos u otro daño al sistema reproductor.

*Lávese las manos después de usar el producto.*