



BAYOU CLASSIC[®]

LPG HOSE ASSEMBLY INSTRUCTION MANUAL

  Failure to follow these instructions could result in fire or explosion which could cause property damage, personal injury or death.

WARNING

For use with outdoor LP gas appliances ONLY!

Not recommended for use in any other application.

Read and Follow all warnings on LPG cylinders and in your outdoor appliance owner's manual.

Only Model M5LPH is intended for use with Gas Grills

KEEP THIS MANUAL FOR FUTURE REFERENCE

For Questions and Information call us at: **1-800-864-6194**

Monday - Friday 7:30am - 4:30pm CST

Barbour International, Inc. • 101 Cypress Way • Brandon, MS 39042

©2015 Barbour International, Inc.


www.thebayou.com

NOTICE:


Restrict the use of this equipment to adults who read, understand, and can follow the warnings and instructions in this manual, on the gas appliance, and LP Cylinder. "Safety Alerts" alone cannot eliminate the hazards that they signal. Strict compliance with these instructions, plus common sense operation, are major accident prevention measures. **Remember, Think Safety and Use Common Sense!**


SAFETY SYMBOLS


The symbols and boxes shown below explain what each heading means. Read and follow the safety warnings and instructions contained in this manual and on the appliance.

 **THE PURPOSE OF THIS SAFETY ALERT SYMBOL IS TO ATTRACT YOUR ATTENTION TO POSSIBLE HAZARDS AS YOU ASSEMBLE AND USE THIS PRODUCT.**

 **THE PURPOSE OF THIS SAFETY ALERT SYMBOL INDICATES FAILURE TO FOLLOW WARNINGS COULD RESULT IN FIRE OR EXPLOSION. PAY CLOSE ATTENTION TO THE INFORMATION WHICH FOLLOWS!**

 → Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

 → Hazard or unsafe practices which could result in severe property damages, personal injury, or death.

 → Hazard or unsafe practices which could result in minor personal injury, product, or property damages.

Carefully read and follow all **WARNINGS, SAFETY PRECAUTIONS, ASSEMBLY and OPERATING INSTRUCTIONS** contained in this manual and in the appliance manual.

DO NOT skip any of the warnings and instructions! SAVE THIS MANUAL FOR FUTURE REFERENCE.

WARNING FOR YOUR SAFETY:

- CONFIRM that the LPG Hose Assembly, you are replacing, conforms to the specifications for the outdoor appliance you are connecting it to.
- This LPG Regulator Hose Assembly is designed to work with an LP gas supply cylinder. DO NOT attempt to connect this hose assembly to any other fuel supply source such as a natural gas line.
- DO NOT attempt to adjust or repair the regulator. A replacement regulator hose assembly can be purchased by contacting Barbour International, Inc. at 1-800-864-6194.
- Read and follow all warnings and instructions provided with your outdoor appliance. If you no longer have your outdoor appliance manual, you should contact the manufacturer for a replacement. For Bayou Classic® products, contact using the information provided on front page of this manual.
- **Do not use high pressure regulator hose assemblies on gas grills. Only Bayou Classic® low pressure Model M5LPH is designed for use on Gas Grills.**
- Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage.
- Read the installation, operation, and maintenance instructions thoroughly before installing or using this equipment.

⚠ DANGER ⚠

IF YOU SMELL GAS:

- 1. Shut off gas to the appliance at the LP cylinder.**
- 2. Extinguish any open flame.**
- 3. If odor continues, keep away from the appliance and immediately call your fire department.**

⚠ DANGER ⚠

If a fire should occur, keep away from the appliance and immediately call your fire department. Do not attempt to extinguish an oil or grease fire with water.

⚠ WARNING ⚠



- A. DO NOT store a spare LP cylinder under or near an outdoor gas appliance.**
- B. Never fill the cylinder beyond 80% full.**
- C. If the information in (A) and (B) are not followed exactly, a fire causing death or serious injury may occur.**

⚠ WARNING ⚠

- LP (propane) gas is colorless, tasteless, heavier than air, and is flammable and explosive. Combustion of propane consumes oxygen and produces carbon monoxide (a poisonous gas). Therefore, never operate an outdoor gas appliance inside a building or confined area where ventilation may be restricted. Make sure the LP Cylinder and outdoor gas appliance is placed in an open area. Do not obstruct flow of combustion and ventilation air.
- Follow lighting procedures as stated with your gas appliance.
- This LP regulator hose assembly is for **OUTDOOR** use only.
- Keep the fuel supply hose away from any heated surfaces.
- Clean and inspect LP hose assembly before each use of the appliance.
If there is evidence of abrasion, wear, cuts or leaks, the hose must be replaced prior to the appliance being put into operation.
Contact Barbour International Inc. to purchase replacement.
- The valve on the propane cylinder is the "ON/OFF" valve. When finished cooking, or in case of an emergency, turn the tank valve clockwise to the "OFF" position. Be sure to close the tank valve after use and before disconnecting the hose.
- Use Bayou Classic® regulator hose assemblies only in accordance with state and local ordinances and codes. In the absence of local codes, installation must conform with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, Storage and Handling of Liquefied Petroleum Gases, ANSI/NFPA 58 or CSA B149.1, Natural Gas and Propane Installation Code; or CGA-B149.2 Installation Code.
- Hose is a trip hazard. Do not walk between outdoor appliance and LP cylinder.

Connecting LPG Hose Assembly to 20-lb LP Gas Cylinder

The LPG Hose Assembly is a pre-assembled unit. Do not take apart or alter in any way. Simply connect the regulator hose assembly to the LP gas cylinder and to the outdoor appliance. An adjustable wrench is needed when connecting hose to the outdoor appliance.

1. Locate your LP regulator hose assembly pictured below.


Follow the instructions. Make sure the valve receptacle on the LP cylinder is clean.

Connect the hose to the cylinder valve by turning the handwheel. Hand tighten.

Caution: If the regulator has a Control Valve, use it to control the "Volume" of Gas **ONLY**. Use the Valve on the Propane Tank to turn Gas Supply "ON" or "OFF".

PRESET REGULATOR WITH VALVE

Increase or Decrease gas flow by turning the valve as indicated on the valve knob.




Model: M2HPH
For use with double burner cookers

Models: M5HPR-1, 7000

Disconnect from Tank **COUNTER-CLOCKWISE**

PRESET REGULATOR

Use the Valve on the Propane Tank to turn Gas Supply "ON" or "OFF".




Model: M3HPH
For use with triple burner cookers

Disconnect from Tank **COUNTER-CLOCKWISE**



PRESET REGULATOR

Use the Valve on the Propane Tank to turn Gas Supply "ON" or "OFF".




Model: M5LPH
For use with Gas Grills

EXTENSION LPG HOSES




ADJUSTABLE REGULATOR



Model: 5HPR-40

ADJUSTABLE REGULATOR


Increase or Decrease gas flow by turning the valve as indicated on the valve knob.



Model: M5HR

ADJUSTABLE REGULATOR

Increase or Decrease gas flow by turning the valve as indicated on the valve knob.




Model: M5HR-30, 7850

2. Connecting LPG Regulator Hose Assembly to Bayou Classic® Outdoor Appliances.


Review Owner's Manual provided with your Bayou Classic® Outdoor Appliance.

If you do not have a Bayou Classic® Outdoor Appliance, refer to the manual supplied with your appliance. **Typical connecting methods are pictured below.**


ALL SINGLE & DOUBLE BURNER COOKERS EXCEPT JET COOKERS




ALL SINGLE BURNER COOKERS USING A BRASS ORIFICE CONNECTOR



ALL BAYOU CLASSIC® JET COOKERS AND BAYOU® FRYERS




BAYOU CLASSIC® TRIPLE BURNER COOKER



3. Connecting Model #MCR1 LPG Hose Assembly to Regulator.

For BAYOU CLASSIC®
GRIDDLE COOKER Model: 2297

Position brass connector on hose at opening under the regulator, and attach by turning brass connector clockwise fully until snug - Hand Tighten.
DO NOT use tools to tighten.



Check for Gas Leaks

After assembly is complete, always check for gas leaks before operating.

⚠ DANGER ⚠

LEAK TESTING:

To prevent fire or explosion hazard:

- DO NOT smoke or permit ignition sources in area while conducting leak test.
- Perform test OUTDOORS only in a well ventilated area.
- Never perform a leak test with a match or open flame.
- Never perform a leak test while the outdoor gas appliance is in use or while hot after use.


⚠ WARNING ⚠

WHEN TO PERFORM A LEAK TEST:

- After assembling your outdoor appliance and before lighting for the first time, even if purchased fully assembled.
- After replacing any regulator hose assembly.
- Every time a 20-lb LP gas cylinder is refilled, or if any of the appliance components are replaced.
- Any time your outdoor gas appliance has been moved.
- At least once per year, or if your outdoor gas appliance has not been used for more than 60 days.

Gas Leak Testing

1. Prepare a soapy water mixture using 50% water and 50% liquid dishwashing soap.
2. Close the LP Cylinder valve, regulator control valve and all appliance control valves.
3. Rotate LP Cylinder Valve counter-clockwise one turn. Gas will flow through and stop at closed appliance control valve(s).
4. Using a small brush or spray bottle, apply soapy water mixture to all connections on cylinder valve, regulator and appliance control valve(s). Repeat procedure for full length of hose. Any expanding bubbles that appear indicate a gas leak at that connection. If so, turn off the gas and tighten leaking connections. Repeat soapy water test until no leaks are detected.
Do Not use outdoor gas appliance if gas leak cannot be stopped.
Contact a qualified appliance repair service.
5. After you are certain there are no leaks, turn LP cylinder valve to "OFF" position. Wait 5 minutes for any gas fumes to evacuate before operating the outdoor appliance.



Spray ALL tank, valve and hose connections with a soapy liquid to check for gas leaks. Appearance of bubbles indicates a leak.

Lighting Instructions

Refer to Owner's Manual supplied with your outdoor appliance for lighting instructions.

ATTENTION: Always turn LP Cylinder Valve and Regulator Control Knob/Valve to OFF position after every use!

Problems with lighting an Outdoor Gas Appliance:

Most LP Hose Regulator assemblies are equipped with a **safety device** to greatly reduce gas flow should the hose be cut or severed. Sometimes this **safety device** may be **activated** when lighting the appliance. To prevent this, **ALWAYS** make sure all valves are in the closed position (LP cylinder valve, regulator, gas control valves). Turn LP cylinder valve one full turn to allow gas to flow to regulator. Then **S-L-O-W-L-Y** open the regulator or gas control valve to allow gas to flow to burner while performing the lighting procedure specified in your outdoor appliance owner's manual. **Does not apply to 5HPR-40**

Safety Precautions & Warnings

For use with Bayou Classic® LP Outdoor Appliances



WARNING



FIRE HAZARD



**READ MANUAL
BEFORE USE**



**NEVER LEAVE
UNATTENDED**




**OUTDOOR USE
ONLY**



**INSURE PROPER
POSITIONING**



**KEEP AWAY FROM
FLAMMABLE
OBJECTS**




**KEEP FLAMMABLE
MATERIALS AWAY**




**KEEP CHILDREN
AND PETS AWAY
FROM COOKER**




**NEVER LEAN
OVER BURNER**




**HOT DURING AND
AFTER USE!**



**USE THERMOMETER
WHEN FRYING**



**NO LID ON POT
WHEN FRYING**



**NEVER USE UNDER
FLAMMABLE
OVERHANG**



**NEVER USE ON
FLAMMABLE
SURFACES**




**TRIP HAZARD
WATCH YOUR STEP**



NO BARE FEET



**KEEP FIRE
EXTINGUISHER
NEARBY**



**ALWAYS PERFORM
GAS LEAK TEST**

Failure to follow these instructions could result in fire or explosion which could cause property damage, personal injury or death!

Remember: Think Safety and Use Common Sense!